


SWITCHES, POTENTIOMETERS, BACK & CONTROL PLATES




Switches

- 8160** LP/TC type, 3 way vertical toggle
- 8160B** As above, budget model
- 8170** SC/TC type, 3 way slide
- 8170S** As above, budget model
- 8171** SC type, 5 position slide
- 5103S** **Schaller** 3 position, open type
- 5105** **Schaller** 5 position, enclosed
- 5105S** **Schaller** megaswitch, 5 position, open type, flexible configuration
- 5105SF** As 5105S, standard SC configuration
- 5110** **Schaller** microswitch, double pole, double throw

Switch Knobs

- 8162** LP type, fits 8160 etc, in black, cream or white
- 5189** **Schaller** LP for treble/rhythm, switch brass, chrome plated
- 5189B** As above, black chrome
- 5191** As above, gold plated
- 8172** SC type, fits 8170 etc, white or black
- 8164** TC vintage type switch backplate, fits 8170, black
- 8163** LP type switch backplate, black, white or cream
- 5153** **Schaller** LP type switch backplate, brass, chrome plated
- 5155** As above, gold plated



Potentiometers and Capacitors

N.B. 'Log' = logarithmic

'Lin' = linear

- 8271** 250K log, high quality
- 8272** 500K log, high quality
- 8273** 250K lin, high quality
- 8274** 500K lin, high quality
- 8275** Capacitor 0.02 Mf for tone control
- 8275A** Capacitor 0.001 Mf for volume control

Switched Potentiometers

Potentiometers incorporating a 'push-pull' or 'push-push' switch for coil tapping etc.

- 8260** 250K log
- 8261** 500K log
- 8262** 250K lin
- 8263** 500K lin
- 8265** 'Push-push' switch

Backplates

- 8152** LP type rear access plates, per pair, black
- 8152C** As above, cream
- 8210** SC type rear access plates, black or white
- 8210MG** SC type, mint green

Control Plates

- 8154** TC type for slide switch, chrome plated
- 8154G** As above, gold plated
- 8154B** As above, black
- 8151** JB type, chrome plated or brass
- 8643** JB type, solid brass