

GIG BAGS - BRASS



Trumpet and Cornet Gig Bags

- 4245 Trumpet / cornet, economy
- 4255 Trumpet / cornet, standard (student)
- 4261 Trumpet / cornet, advanced

Trombone Gig Bags

- 4248 Tenor trombone / economy
- 4256 Tenor trombone, standard (student)
- 4263 Tenor trombone, advanced
- 4258 Bass trombone / tenor saxophone, standard (student)
- 4269 Bass trombone / tenor saxophone, advanced

Flugelhorn Gig Bags

- 4246 Flugelhorn / alto saxophone, economy
- 4257 Flugelhorn / alto saxophone, standard (student)
- 4267 Flugelhorn / alto saxophone, advanced

for pictures of the above, see page B83



4258T

A stylish modern range of versatile gig bags for the player on the move. Designed by musicians for musicians.

Economy range: Thickly padded rayon, grab handle, back straps and accessory pocket

Standard (student) range: Durable rayon canvas, high density internal foam padding

Advanced range: As standard range, made from deluxe soft durable NYCROFLEX™

Economy and standard (student) ranges available in 4 colours:

purple, turquoise, red and yellow

Advanced range available in 4 colours: green on black (GN), grey on black (GY), black on grey (B) and black on purple (P)



4255



4256Y

4261GY