


# CELLO PEGS, BASS MACHINES & VIOLIN & VIOLA ENDPINS



## Cello Pegs

- 1200** Hardwood, black stained  
4/4, 3/4, 1/2
- 1036** Ebony, 4/4, 3/4, 1/2, 1/4, 1/8
- 1453** Rosewood,  
4/4, 3/4, 1/2, 1/4, 1/8

## Cello Pegs, Fine Quality

- 1356** Ebony or rosewood, French,  
Bausch or Swiss pattern
- 1454** English pattern, ebony,  
rosewood or boxwood
- 1384** Swiss pattern with inlaid eye,  
ebony or rosewood

## Schaller Cello Pegs

- 5740** Set of four Schaller non slip  
pegs, fully adjustable, (4/4-3/4)

## Bass Machines


- 1073** Quarter plate, brass, set of four
- 1051** Full plate, fine quality,  
engraved brass plates
- 1051F** As 1051 above, 1/4 size
- 1051/5** As above for five strings

## Violin and Viola Endpins

- 1008** Ebony or rosewood
- 1462** Ebony or rosewood, Parisienne eye
- 1463** English pattern, ebony, rosewood or boxwood, black or white button



1008      1462      -      -      1463      -      -



## String Winder

- 1826** Double Bass string winder
- 1827** D. Bass deluxe string winder,  
solid brass